


DRILL AND FILL METHOD:

FOAM EXTERIOR DRILL $\frac{3}{8}$ " DIA. HOLES IN PANEL CONNECTION @ 10" O.C. FOR WALL PANELS & @ 6" O.C. FOR ROOF PANELS ALONG ENTIRE LENGTH OF JOINT. INJECT FOAM INTO CAVITY FOR APPROX. 5 SECONDS. FOAM MUST BE ALLOWED TO CURE FOR AT LEAST 24 HOURS BEFORE HARDENED FOAM BALLS ARE REMOVED FROM THE EXTERIOR. INJECT FOAM AS CLOSE AS POSSIBLE TO INTERIOR SKIN OF PANEL.

Plywood Spline Detail - No Timber
 * Structural Panel
 SCALE: 1" = 1'-0"

| | | | | | |
|---|--|--|--|-----------------|---|
|  incorporated P.O. Box 185, West Chesterfield, NH 03466 (603) 256-8800 | | Standard Detail Library | | DRAWING: | * |
| | | Typical Plywood Spline Detail Structural Panel - Timber | | DRAWING NUMBER: | * |
| DRAWN BY: JTC | | DRAWN BY: JTC/TGM | | | |
| DRAWING DATE: 8.4.05 | | PRINTED DATE: 8.4.05 | | | |